

LUKAS


Because you never get a second chance

Operating instructions for rescue equipment

CE



Spreaders



171010085 GB
Edition 07.2010
replaces 04.2008




(Translation of the original operating instructions)

Content	Page
1. Hazard classes	4
2. Product safety	5
3. Proper use	8
4. Description of the functions	9
4.1 <i>Description</i>	9
4.2 <i>Unit in detail</i>	10
4.3 <i>Circuit diagram</i>	11
4.4 <i>Control of the operating movements</i>	11
4.5 <i>Hydraulic supply</i>	11
4.6 <i>Hoses</i>	11
5. Connecting the equipment	12
5.1 <i>General information</i>	12
5.2 <i>Coupling the mono-couplings</i>	12
5.3 <i>Coupling the quick-disconnect-couplings</i>	14
6. Operation	15
6.1 <i>Preparatory measures</i>	15
6.2 <i>Operating the star grip</i>	15
7. Spreading, pulling, peeling and squeezing	16
7.1 <i>Safety notes</i>	16
7.2 <i>Spreading</i>	16
7.3 <i>Pulling</i>	18
7.4 <i>Peeling</i>	18
7.5 <i>Squeezing</i>	19
8. Dismantling the equipment / deactivation following operation	20
8.1 <i>Spreader</i>	20
8.2 <i>Hydraulic unit</i>	20
8.3 <i>Hoses</i>	20
9. Maintenance and service	20
9.1 <i>Spreader, overall</i>	21
9.2 <i>Protective equipment</i>	21
10. Repairs	22
10.1 <i>General information</i>	22
10.2 <i>Preventative service</i>	23
10.3 <i>Repairs</i>	24
11. Troubleshooting	35

12. Technical data	37
12.1 <i>Peeling</i>	42
12.2 <i>Recommended hydraulic fluid</i>	42
12.3 <i>Operating and storage temperature ranges</i>	42
13. EC Declaration of conformity	43
14. Notes	44

1. Hazard classes

We distinguish between various categories of safety notes. The table below gives you an overview of the assignment of symbols (pictograms) and key words to the specific hazard and possible consequences.

Pictogram	Damage / injury to	Key word	Definition	Consequences
	human	DANGER!	Immediate danger	Death or major injury
		WARNING!	Potentially dangerous situation	Potential death or major injury
		CAUTION!	Less dangerous situation	Minor or slight injury
	device	CAUTION!	Danger of damage to device / environment	Damage to the equipment, damage to the environment, damage to surrounding materials
	-	REMARK	Advice for application and other important / useful information and advice	No injury / damage to persons / environment / equipment



Wear helmet with face protection



Wear safety gloves



Wear safety shoes



Proper recycling



Observe principles of environmental protection



Read and observe operating instructions

2. Product safety

LUKAS products are developed and manufactured in order to guarantee the best performance and quality when used properly.

Operator safety is the most important aspect of the product design.

Moreover, the operating instructions are intended to help the safe use of LUKAS products.

The generally applicable, legal and other binding regulations pertaining to the prevention of accidents and protection of the environment apply and are to be implemented in addition to the operating instructions.

The equipment may only be operated by persons with appropriate training in the safety aspects of such equipment – otherwise, there is a danger of injury occurring.

We would like to point out to all users that they should read carefully the operating instructions and the instructions contained therein before they use the equipment, and that they should carefully follow such.

We further recommend that a qualified trainer train you in the use of the product.



WARNING / CAUTION!

The operating instructions for the hoses, the accessories and the connected hydraulic equipment must also be observed!
















Even if you have already received instructions on how to use the equipment, you should still read the following safety notes through again.










WARNING / CAUTION!

Ensure that the accessories and connected equipment used are suitable for the max. operating pressure!

	<p>Please ensure that no body parts or clothing get stuck between the visibly moving parts (e.g. spreader arms).</p>	<p>It is prohibited to work under load if this load is lifted exclusively by hydraulic equipment. If this work is absolutely imperative, additional mechanical supports must be used.</p>	
	<p>Wear protective clothing, safety helmet with visor, protective gloves</p>	<p>Inspect the equipment before and after use for visible defects or damage</p>	
 	<p>The responsible department is to be informed immediately of any changes (including to the operating behaviour)! If necessary, the equipment is to be deactivated immediately and secured!</p>	<p>Inspect all cables, hoses and screwed connections for leaks and externally visible damage! If necessary, repair immediately! Squirting oil can result in injuries and fires.</p>	

	<p>In the event of malfunctions, immediately deactivate the equipment and secure it. The malfunction is to be repaired immediately.</p>	<p>Do not carry out any changes (additions or conversions) to the equipment without obtaining the prior approval of LUKAS.</p>	
	<p>Observe all safety and danger notes on the equipment and in the operating instructions.</p>	<p>All safety and danger notes on the equipment are to be kept complete in a legible condition.</p>	
	<p>Any mode of operation which impairs safety and/or stability of the equipment is forbidden!</p>	<p>Comply with all specified dates or dates specified in the operating instructions pertaining to regular controls / inspections on the equipment.</p>	
	<p>Safety devices may never be deactivated!</p>	<p>The maximum permitted operating pressure noted on the equipment must not be exceeded.</p>	
	<p>Before the equipment is switched on/started up, and during its operation, it must be ensured that nobody is endangered by the operation of the equipment.</p>	<p>Only original LUKAS accessories and spare parts may be used for repairs.</p>	
		<p>Please ensure that, when working with this equipment or during transportation of such, you don't get stuck in the looped hoses and trip.</p>	
	<p>When working close to live components and cables, suitable measures must be taken to avoid current transfers or high-voltage transfers to the equipment.</p>	<p>Please note that, when spreading, tearing or breaking can cause falling material, or sudden removal of such can cause it to suddenly catapult off: necessary precautions need to be taken.</p>	
	<p>The build-up of static charge with the potential consequence of spark formation is to be avoided when handling the equipment.</p>	<p>Only touch any broken-off parts wearing protective gloves, since the torn edges can be very sharp.</p>	

	<p>The equipment is filled with a hydraulic fluid. These hydraulic fluids can be dangerous to health if swallowed or their vapours inhaled. Direct contact with the skin is to be avoided for the same reason. Please also note that hydraulic liquids can also have a negative effect on biological systems.</p>	<p>When working with or storing the equipment, ensure that the function and the safety of the equipment are not impaired by the effects of stark external temperatures or that the equipment is damaged in any way. Please note that the equipment can also heat up over a long period of use.</p>	
	<p>Ensure adequate lighting when you are working.</p>	<p>Before transporting the equipment, always ensure that the accessories are positioned such that they cannot cause an accident.</p>	
	<p>Always keep these operating instructions within reach where the equipment is used.</p>	<p>Ensure the proper disposal of all removed parts, left-over oil, left-over hydraulic fluid and packaging materials!</p>	 

The generally applicable, legal and other binding national and international regulations pertaining to the prevention of accidents and protection of the environment apply and are to be implemented in addition to the operating instructions.

W A R N I N G / C A U T I O N !

The equipment **is to be used exclusively** for the **purpose stated in the operating instructions (see chapter “Proper Use”)**. Any other or further use is **not considered proper use**. The manufacturer / supplier is not liable for any damages resulting from improper use. The user bears sole responsibility for such. Observance of the operating instructions and compliance with the inspection and maintenance conditions are part of the proper use.


Never work when you are overtired or intoxicated!


3. Proper use

LUKAS spreaders are designed especially for rescue services. They are used to release persons trapped as a result of a road accident e.g. by forcing open the car doors (see below Fig. 1) or by squashing other parts of the vehicle. In other catastrophic situations they are used to lift (by spreading) or to displace objects in order to rescue buried or trapped persons, e.g. by concrete components in collapsed houses (see below Fig. 2), and to squash constructional components, e.g. pipes.

In principle, objects can be pulled, spread, squashed or compressed in length.

All objects to be worked on are to be secured using stable supports or substructures.

When lifting loads, additional risks to the operator and/or persons not involved may be posed if the load moves in an uncontrolled manner or if the spreader slips or tips over. When applying the tool and lifting, make sure that there is no danger, if necessary by using additional supports or safety devices.



fig. 1



fig. 2

LUKAS spreaders and combi tools can also be used under water at a depth of up to 40m (131 ft).



CAUTION!

In this case, you must strictly observe any leaks in order to avoid threats to the environment.



CAUTION!

All objects which are to be worked on are to be secured using stable supports or substructures.



WARNING / CAUTION!

The following may not be squeezed:

- **live cables**
- **hardened** parts such as springs, spring steels, steering columns and rollers
- explosive bodies such as airbag cartouches

NEVER operate the rescue equipment at a higher operating pressure than that stated in the chapter "Technical data". A higher setting can result in material damage and/or injuries.

LUKAS rescue equipment may only be used in areas at risk of explosion if an explosion has been prevented by appropriate measures. You must also take into account that sparks may be created, for example by spreading or squashing an object.

When working in areas at risk of explosion, all applicable legal, national and international regulations, standards and safety rules for avoiding explosions must be observed without limitation!

Spare parts and accessories for the rescue tool can be ordered from your authorised LUKAS-dealer!

4. Description of the functions


4.1 Description

The equipment is designed such that, via a hydraulically activated piston, two equal, opposite spreader arms are symmetrically opened by mechanical joints, thereby spreading objects. Closing the spreader arms is also carried out hydraulically and mechanically by reverse order of the piston.

All spreaders ensure full load-holding function when disconnected from the hydraulic supply (e. g. when being unintentional decoupled; defective hose, and so on).


(For reasons of safety, equipment SP 510 and SP 512 are internally safeguarded from 63 MPa = 630bar. When the safeguarding valve responds a screeching noise can occur. Even if the screeching noise occurs in unloaded condition, deactivate the equipment immediately and contact your authorized dealer or LUKAS directly!)

4.2 Unit in detail




- 1 Star grip
- 2 Control valve
- 3 Spreader body
- 4 Handle
- 5 Hand guard
- 6 Spreading arm
- 7 Tip with borehole for chain set
- 8 Roll pin
- 9 Pressure hose
- 10 Return hose
- 11 Handhold
- 12 Mono-coupling male
- 13 Quick-disconnect coupling (male)
- 14 Quick-disconnect coupling (female)

Quick-disconnect coupling system:



4.3 Circuit diagram

To enable comprehension of the function, a simplified hydraulic cylinder of the rescue equipment (A) + hand valve (B) are depicted here.



4.4 Control of the operating movements

The spreading arms movement is controlled via the star grip of the mounted valve. (see cover, item 1 and, below, figure 3).



fig. 3

star grip

4.5 Hydraulic supply

A LUKAS motor pump or hand pump only may be used to drive the equipment. If the pump unit is a different make, you must make sure that it complies with LUKAS specifications, otherwise potential dangers may occur which are not the responsibility of LUKAS.

Ensure in particular that the authorised operating pressure for LUKAS equipment is not exceeded.



REMARK:

Before you use pumps from a different manufacturer, you must contact LUKAS or an authorised dealer.

4.6 Hoses

The pump unit and the rescue tool are connected by hoses.

5. Connecting the equipment

5.1 General information

There are two short hoses on the side of the equipment: they are connected to the pump unit via two hoses. All hose assemblies are marked with a colour and have couplings to enable unmistakable connection.



REMARK:

The devices can be equipped with different coupling systems. They differ only by the article number and not by the designation. Of course the coupling systems can also be reequipped at a later time.




WARNING / CAUTION!

Before connecting the equipment you have to pay attention that **all used components** are suitable to the **max operation pressure of the pump unit!** In the case of doubt you **have to inquire LUKAS** directly!

5.2 Coupling the mono-couplings

The equipment is connected to the hydraulic pump via mono-coupling halves (male and female).



Before coupling, remove dust protection caps, then connect male and female, and turn the locking sleeve of the female to direction „1“ until the locking sleeve locks into place. The connection is now in place and secure. Decoupling is by turning the locking sleeve to direction „0“.
The equipment can also be coupled under pressure provided the connected equipment is not activated.




REMARK:

We **recommend** coupling the coupling halves in a **pressureless** state, when working in areas with low ambient temperature and the usage of extension hose assemblies / hose reels, otherwise decoupling could need very high expenditure of force.

To protect them from dust, the accompanying dust protection caps must be put back on.

Using the dust protection caps:

The “A” dust protection caps have two internal pins “B”. The dust protection caps must be placed on the coupling pins in such a way that the pins are guided into the “C” grooves. Fasten the screw up to the limit stop to fix the dust protection caps on the coupling pins.





WARNING/CAUTION!

The mono-couplings **may not** be **screwed off** the hose assemblies and / or the hose assemblies be **confused!**



5.3 Coupling the quick-disconnect-couplings

The equipment is connected to the hydraulic pump via quick-disconnect-coupling halves (male and female).



Before coupling unlock the connect socket by turning the sleeve into position X. Retract sleeve and connect plug and socket. Release sleeve and turn it into position Y. Now the connection has been made and locked. Uncoupling is done in the reverse order.



CAUTION!

Always connect the return line first and afterwards the supply line!



REMARK:

Coupling of the devices is only possible, when the hoses are **depressurized**.

To protect them from dust, the accompanying dust protection caps must be put back on.



WARNING/CAUTION!

The quick-disconnect-couplings partly have special functions. Therefore it is not allowed to **screw** them **off** from the hoses or to **exchange** them!



6. Operation

6.1 Preparatory measures

6.1.1 Commissioning

Before commissioning and following repairs, the equipment must be deaerated.

- Connect the equipment to the hydraulic pump (see chapter “Connecting the equipment”).
- Open / close the spreader arms of the equipment without any load at least twice (see chapter “Operation of the star grip”).



REMARK:

We recommend that during the deaeration, the attached aggregate for the hydraulic supply should stand on a higher level than the body of the rescue tool.

Recommended procedure for the deaeration of the rescue tool:

- 1.) open and close fully with the spreader arms facing **upwards**.
- 2.) open and close fully with the spreader arms facing **downwards**.
- 3.) open and close fully with the spreader arms facing **upwards**.
- 4.) open and close fully with the spreader arms facing **downwards**.

6.1.2 Inspection of the pump unit

➔ See separate operating instructions for the relevant unit (or for the hand pump).



REMARK:

Before each start-up of the hydraulic unit you have to make sure that the actuating valves are set to depressurized circulation.



REMARK:

Before coupling the quick-disconnect couplings, the actuating valves of the hydraulic unit are set to depressurized circulation.

If you use mono-couplings, you can also couple when the hoses are pressurized!

6.2 Operating the star grip

Opening the device ():

Turn the star grip in a clockwise direction (in the direction of the relevant symbol) and keep in this position.

Closing the device ():

Turn the star grip in an counterclockwise direction (in the direction of the relevant symbol) and keep in this position.

“Dead-man’s” function:

Following release, the star grip automatically returns to the central position, guaranteeing the full load-holding.



7. Spreading, pulling, peeling and squeezing

7.1 Safety notes

Before rescue works can commence, the position of the obstacle must be stabilised. You must ensure an adequate substructure and / or adequate support of the object. World-wide, safety guidelines pertaining to the specific country are to be observed and complied with. In the Federal Republic of Germany, regular safety inspections according to the regulations of the Gesetzliche Unfallversicherung (GUV; connoted 'Legal accident insurance') are mandatory.

In the event of a potentially explosive situation, it is not permitted to use motor pumps (danger of the formation of sparks). In such cases, hand pumps are to be used.

The following are to be worn when working with the rescue equipment:

- protective clothing,
- safety helmet with visor or protective goggles,
- protective gloves
- and, if necessary, ear protection

Before activating the rescue equipment, always ensure that there is no danger to persons either involved / uninvolved in the action by the movement of the rescue equipment or by flying fragments. Further avoid unnecessary damage to property belonging to others, objects not involved by the rescue equipment / flying fragments.



Reaching between the spreader arms is strictly forbidden!



WARNING / CAUTION!

The particular effect of the force of the rescue equipment during operation could cause pieces of the vehicle to break off or fly off, posing a danger to persons. Those not involved in the rescue operation should therefore **keep at a distance appropriate to the situation.**

7.2 Spreading

Use the front area of the tips for increasing the gap only. Full spreading capacity can be achieved when approximately half of the grooved area of the tips is used. The greatest force is created in the rear area of the spreading range of the tip.




WARNING / CAUTION!



The arms – made from a light metal alloy – **may not be damaged.**




SP 310, SP 510 and SP 512:




SP 300:



Working surface is too small, tips slip off. Only for increasing the size of a gap (not suitable for spreading)




Tips get a safe grip.



Work with the tips only. Do not damage the arms.


7.3 Pulling

- LUKAS chain sets are to be used for pulling purposes.
- Before the pulling process can be performed, ensure that the bolt and hook fit correctly to prevent the chain from slipping.
- Only chain sets in perfect condition may be used.
- The pull chains are to be inspected at least once per year by an expert.
- See separate operating instructions for the relevant chain set!



7.4 Peeling

With the integrated peeling zone (see figure below) in the tool tips of spreaders SP 310, SP 510 and SP 512, sheet steels can be peeled open (for maximum sheet steel thickness t , see chapter "Technical data").



WARNING / CAUTION!

Splinters can fly uncontrollably from particularly hard materials.
Keep a safe distance!

7.5 Squeezing


Basically, squeezing may only be carried in the area of the tips, unless an additional squeezing device is used – see figures 6 and 7 below. (This additional squeezing device is only available as an accessory for the spreader SP 310).

fig. 6



Squeezing plates A

fig. 7



Use of this squeezing device enables squeezing closer to the spreader arm pivot point, resulting in a higher squeezing force.




fig. 8

Assembly:

1. Push the squeezing plate A over the spreader arm until boreholes B1 and B2 lie flush above each other.
2. Position the spacer washer C between the two boreholes..
3. Put the screw B from the opposite side of the spreader arm through borehole B1 and spacer washer C (see figure 9).
4. Screw the screw B tightly into borehole B2.




fig. 9

8. Dismantling the equipment / deactivation following operation

8.1 Spreader

Once work has been completed, the spreader arms are to be closed so that there is a tip distance of just a few mm. This relieves the hydraulic and mechanical strain on the equipment.

8.2 Hydraulic unit

Upon completion of work, the unit must be deactivated.

8.3 Hoses

First of all, decouple the pressure hose then the return hose as described in chapter "Connecting the equipment". Ensure that you put the dust protection caps back on to the couplings.

9. Maintenance and service

The equipment is subject to very high mechanical stresses. A visual inspection is to be carried out after every use: however, at least one visual inspection is to be carried out annually. These inspections enable the early detection of wear and tear, which means that punctual replacement of this wearing parts prevents breakages from occurring. A function test is also to be carried out every three years or should there be any doubt regarding the safety or reliability of the equipment.

(Please also observe the relevant valid national and international regulations pertaining to service intervals of rescue equipment). In the Federal Republic of Germany, regular safety inspections according to the regulations of the Gesetzlichen Unfallversicherung (GUV; connoted 'Legal accident insurance') are mandatory.



CAUTION!

Clean off any dirt before controlling the equipment!



WARNING / CAUTION!

In order to carry out maintenance and repair works, tools appropriate for the job and personal protecting equipment are essential.



9.1 Spreader, overall

Inspections to be carried out:

Visual inspection

Spreader

- Opening width of the spreader arms on the tips (see chapter “Technical data”),
- General tightness (leaks),
- Operability of the star grip,
- Existence and stability of handle,
- Labels completely existent and legibly,
- Covers in perfect condition,
- Couplings must be easy to couple,
- Dust protection caps must be available.

Spreader arms

- Spreader arms free of tears and without any chipped spots or deformations on the surfaces,
- Bolts and retaining rings of the spreader arms must be present and in correct working order,
- Grooving of the tips must be clean and squared, and not have any tears
- Tips existent and locked (for SP 300)

Hoses (see also operating instructions for hydraulic hoses)

- Visual control for visible damage,
- Control for leaks.

Function test

- Opening and closing function flawlessly upon activation of the star grip,
- no suspicious noises.
- no further movement of the spreader arms upon interruption of the valve activation during the process (“dead-man’s” function)

9.2 Protective equipment

- Control of the protective equipment on / around the rescue equipment, especially the hand guard of the moveable parts (they must be free of tears!).

10. Repairs

10.1 General information

Servicing may only be carried out by the manufacturer or personnel trained by the manufacturer and by authorised LUKAS dealers.

Only LUKAS spare parts may be used to replace all components (see spare parts list) since special tools, assembly advice, safety aspects, inspections might have to be complied with (see also chapter "Maintenance and Service").

During assembly, ensure the complete cleanliness of all components, since dirt can damage the rescue equipment!



WARNING / CAUTION!

Protective clothes must be worn when repairs are being carried out, since parts of the units can also be pressurised in an idle state.



REMARK:

Please always return the guarantee registration card to LUKAS Hydraulik GmbH or register your tool on the LUKAS website. Only then are you entitled to the extended guarantee.



REMARK:

Before you use couplings from a different company, you must contact LUKAS or an authorised dealer.



REMARK when using the quick-disconnect-coupling system:

Overpressure protection of the rescue equipment

(model with yellow coupling nipple on the return hose)

If the equipment's short hoses are not connected to a unit, temperature increases can inadvertently cause pressure to build up in the equipment. Hence, the return hose of the equipment is equipped with a safety coupling (quick-disconnect coupling male, yellow). Unwanted overpressure (approx. 1.5 Mpa) is automatically released via this nipple: hydraulic fluid leaks.

Should a hydraulic fluid leak on the coupling male be more frequent, please contact your dealer or LUKAS itself.

If couplings from a different company are used which do not have this function, the overpressure protection can react in the valve of the rescue equipment. Hydraulic fluid leaks in the area of the star grip. Following the reduction in pressure, the valve is once again tight.

Should the valve leak permanently, please immediately contact your dealer or LUKAS itself.



CAUTION!

Because LUKAS rescue equipments are appropriate for highest achievements, only components may be exchanged, which are specified in the spare parts list of the appropriate equipment.

Further components of the equipment may only be exchanged, when:

- you have participated on a appropriate LUKAS service training.
- you have the explicit permission of the LUKAS Service department (After inquiry, an examination for the distribution of permission is being carried out. An examination in each individual case is necessary!)

10.2 Preventative service

10.2.1 Care regulations

The exterior of the equipment is to be cleaned from time to time in order to protect it from external corrosion. Oil is to be applied to the metallic surfaces.

10.2.2 Function and load test

If there is any doubt regarding the safety or reliability of the equipment, a function and load test must also be performed.

LUKAS offers appropriate test equipment to this end.

10.2.3 Changing the hydraulic fluid

- The hydraulic fluid must be changed after the equipment has been used approx. 200 times / after three years at the latest.
- It must always be changed whenever the hydraulic fluid for the accompanying pump (motor / hand pump) is changed. This is to prevent the fresh hydraulic fluid from becoming contaminated by the used fluid from the rescue equipment.

Procedure:

1. Close spreader arms (until the tips are almost touching).
2. Change the hydraulic fluid of the pump. Please observe the separate operating instructions for the pump being used!
3. Screw off the return hose on the pump:
 - **when the hose connection is directly into the pump:**
completely unscrew the connection nut of the connection piece of the blue return hose.
 - **when the hose connection is via mono-coupling to the pump:**
remove the cover from the mono-coupling (male).
completely unscrew the connection nut of the blue return hose on the mono-coupling (male).
 - **when the hose connection is via quick-connect-coupling to the pump:**
completely unscrew the connection nut on the quick-disconnect-coupling of the blue return hose.
4. Put the return hose into a separate collecting basin for the hydraulic fluid still in the equipment.
5. Slowly open the tool (the pump must be working during this time). The old hydraulic fluid from the piston space side runs via the return hose into the separate collecting basin, and is to be disposed of in the same manner as the old hydraulic fluid of the pump.
6. Switch the pump off (motor pump) / no longer activate it (e.g. hand pump).
7. Reconnect the return hose to the pump:
 - **when the hose connection is directly into the pump:**
screw the connection nut of the connection piece of the blue return hose back on.
(Please observe the necessary torque of $M_A = 40 \text{ Nm!}$)
 - **when the hose connection is via mono-coupling to the pump:**
screw the connection nut of the blue return hose back onto the mono-coupling (male).
(Please observe the necessary torque of $M_A = 40 \text{ Nm!}$)
Pull back the cover on the couplings as far as the limit stop.
 - **when the hose connection is via quick-connect-coupling to the pump:**
screw the connection nut back onto the quick-disconnect-coupling of the blue return hose.
(Please observe the necessary torque of $M_A = 35 \text{ Nm!}$)
8. Deaerate the rescue tool as described in the chapter "Preparatory measures".

10.3 Repairs

10.3.1 Chaging the tip (SP 310, SP 510 and SP 512)

Procedure:

1. Use the pulling pin to remove the roll pin “A”,
2. Replace tip,



CAUTION!

Before assembly, apply LUKAS special grease to all sliding surfaces after having thoroughly cleaned them.

3. Hammer in new roll pin.




CAUTION!

Before assembly, apply LUKAS special grease to all sliding surfaces after having thoroughly cleaned them.
Also observe the installation position of the adapter sleeve to ensure optimum force distribution!


Installation position of the roll pin of the SP 310 and SP 510:

The opening of the roll pin should face towards the squeezing surfaces (see figure, right)



Installation position of the spiral pin of the SP 512:

The external start of the spiral pin should face towards the rear end of the tip (see figure, right)



The roll pin / spiral pin comes with the tip. Pressing onto the tips on the spreader arm enables the roll pins to be inserted more easily into the boreholes.




REMARK:

Always replace both tips.

10.3.2 Replacing the plug-on tips (SP 300)

Procedure:

1. In order to remove the plug-on tips “G”, you need to push the buttons “J” on both sides of a spreader arm completely and simultaneously and then remove the plug-on tip from the spreader arm by pulling it forwards.
2. Place the new tips onto the arm until they automatically click in place on the spreader arm.



NOTE:

Always replace both plug-on tips.

When inserting the new tips, push both buttons “J” until the tip can be slid over them.

After fitting, make sure that both buttons “J” are locked on each arm (that they are back in their original position).

10.3.3 Changing or tightening hoses

Hoses of the pressure and/or return pipe leaks or hoses are defective. Tighten the hoses on the safety valve.

(Please note! Observe torque of $M_A = 40 \text{ Nm!}$)



REMARK when using mono-couplings:

If you want to change the hoses, you have to dismantle the mono-couplings.



CAUTION (by usage of mono-coupling-system)!

Take care that the port 'T' of the rescue tool is always connected to the port 'T' of the mono-coupling.




CAUTION (by usage of quick-disconnect-coupling-system)!

The return hose, which is screwed onto the port "T" of the rescue tool, must be equipped with a quick-disconnect-coupling (male) always. However the supplying hose line must be equipped with a quick-disconnect-coupling (female).

Procedure:

1. Loosen the 2 B screws in the handle sleeve with quick-disconnect protective sleeves C (hexagon socket)




2. Remove handle sleeve A and tighten screwed connection. If necessary, renew seals.

3. Dismantle hose D and sealing ring E. (There is no need to carry out this point if the hoses are just being tightened).

4. Screw the hose with sealing ring back on. Please ensure that the insulating washer F is on and correctly assembled.

5. Tighten the hose connection on the safety valve. (Please note! Observe the necessary torque of $M_A = 40 \text{ Nm!}$)

6. Then replace handle sleeve, protective sleeves and screws, tighten (Torque: 5Nm) and secure it with threadlocking fluid (e. g. LOCTITE 243).





10.3.4 Spreader arm, spreader tips, protection cover and handle replacement (SP 310, SP 510 and SP 512)

Components to be replaced	Required work steps
Handle	1. - 3. and 7.
Protective cover	1. - 4. and 7.
Plug-on tips	1. - 5. and 7.
Lever links	1. - 5. and 7.
Spreader arms	1. - 6. and 7.

Procedure:


1. Close the rescue unit until a gap of only a few mm remains between the tips. Disconnect the device from the hydraulic power supply unit and clean thoroughly.


2. Unscrew nuts "A", remove washers "B" and remove fixing bolts "C".



3. Pull the handle "D" backwards over the hose connections.


4. In the same way, pull the protective cover "E" backwards over the hose connections.





5. Drive the pins "F" out with a drift and remove the plug-on tips "G". Remove the locking rings "H" and remove the handlebars "J".

6. The pins "L" can be removed after removing the locking rings "K". You can now remove the spreader arms "M" and replace them.



7. The work steps must be carried out in reverse order to fit the new parts.



CAUTION!

Don't forget to apply LUKAS special grease to all sliding surfaces.



NOTE:


The torque required can be taken from the spare parts list of your particular unit.

10.3.5 Spreader arm, spreader tips, protective cover and handle replacement on the SP 300 spreader


Components to be replaced	Required work steps
Handle	1., 2. and 8.
Protective cover	1., 5. and 8.
Plug-on tips	1. - 4. and 8.
Lever links	1. - 4., 6. and 8.
Spreader arms	1. - 6. and 8.

Work steps:


1. Close the rescue unit until a gap of only a few mm remains between the tips. Disconnect it from the hydraulic power supply unit and clean thoroughly.




2. Remove the fixing screws "A" and remove the handle "B".




3. Remove the screws "C" and "D".




4. Remove the two-piece locking elements "E" on the protective cover "F" and remove the two-piece protective cover by pulling it sideways.




5. In order to remove the plug-on tips “G”, you need to push the buttons “J” on both sides of a spreader arm completely and simultaneously and then remove the plug-on tip from the spreader arm to the front.



6. You need to remove the locking rings “K” and the lever links “L” to replace the spreader arms “H”.



7. Also remove the locking rings “M” and remove the pins “N”. You can then remove the spreader arms “H”.



8. The work steps must be carried out in reverse order to fit the new parts.



CAUTION!

Don't forget to apply LUKAS special grease to all sliding surfaces.



NOTE:

The torque required can be taken from the spare parts list of your particular unit.

10.3.6 Mono-couplings

The mono-couplings must be replaced in the event of:

- external visible damage,
- the locking device not working,
- hydraulic fluid continually leaking in a coupled/uncoupled state.



WARNING / CAUTION!


Never repair couplings: they are to be replaced by original LUKAS parts!




During assembly, tighten the connection nut of the hose assembly with a torque of $M_A = 40 \text{ Nm}$.

Procedure:

1. Remove the cover from the couplings.



2. Loosen the connection nuts of the hose assembly and remove the coupling.



3. Position the new coupling and tighten the connection nuts of the hose assemblies with a torque of $M_A = 40 \text{ Nm}$ and push the cover of the couplings back on.



CAUTION!

Take care that the port 'T' of the rescue tool is always connected to the port 'T' of the mono-coupling.

10.3.7 Quick-disconnect-couplings

The quick-disconnect-couplings must be replaced in the event of:

- external visible damage,
- the locking device not working,
- hydraulic fluid continually leaking in a coupled/uncoupled state.



WARNING / CAUTION!

Never repair couplings: they are to be replaced by original LUKAS parts!



During assembly, tighten the connection nut of the hose assembly with a torque of $M_A = 35 \text{ Nm}$.

Procedure:

1. Loosen the connection nut of the hose assembly and remove the coupling.
2. Position the new coupling and tighten the connection nut of the hose assemblies with a torque of $M_A = 35 \text{ Nm}$.



CAUTION!

The return hose, which is screwed onto the port "T" of the rescue tool, must be equipped with a quick-disconnect-coupling (male) always.

However the supplying hose line must be equipped with a quick-disconnect-coupling (female).

10.3.78 Valve cover

If the cover is deformed to such an extent that the star grip no longer works correctly, the valve must be replaced in its entirety.

Have repairs carried out by an authorised dealer, by personnel specially trained by LUKAS, or by LUKAS customer service only.

10.3.9 Labels

All damaged and/or illegible labels (safety notices, type plate, etc.) must be renewed.

Procedure:

1. Remove damaged and/or illegible labels.
2. Clean the surfaces using industrial alcohol.
3. Attach new labels.

Ensure that you attach the labels in the right position. If you are no longer sure about this, then please contact your authorised LUKAS dealer or LUKAS itself.

11. Troubleshooting

Trouble	Control	Cause	Solution
Spreader arms move slowly or jerkily when activated	Are the hoses connected properly?	Air in the hydraulic system	Deaerate pump system
	Does the pump unit work?		
Device doesn't perform at its given power	Check the hydraulic fluid level in the supplying pump	Insufficient hydraulic fluid in the pump	Top up hydraulic fluid, deaerate
Following release, the star grip doesn't return to the central position	Cover damaged or star grip hard to move?	Damage to the torsion spring for reset	Repair by an authorised dealer, by personnel specially trained by LUKAS, or by LUKAS itself
		Soiled valve or star grip	
		Defective valve	
		Other mechanical damage (e. g. star grip)	
<u>with mono-coupling-system:</u> Hoses cannot be coupled		Pressure too high (e.g. caused by too-high ambient temperature)	Set hydraulic pump to pressureless circulation
		Coupling defective	Coupling needs to be replaced immediately
<u>with mono-coupling-system:</u> It is frequently not possible to couple hose assemblies	Control the degree of viscosity and application temperature of the used hydraulic fluid	Hydraulic fluid not adapted to the application situation	Hydraulic fluid must be replaced (see chapter "Recommended Hydraulic fluids")
		Coupling defective	Coupling needs to be replaced immediately
<u>with quick-disconnect-coupling-system:</u> Hoses cannot be coupled	Is the pump working?	Pressurized	Relieve pump
		Coupling defective	Coupling needs to be replaced immediately
Hydraulic fluid leak on the hoses or the fixing-ins	Are the hoses defective?	Leak, possible damage	Replace hoses

Trouble	Control	Cause	Solution
Damages on the surface of the hydraulic hoses		Mechanical damages or contact with aggressive agents	Replace hoses
Hydraulic fluid leaks on the piston rod		Defective rod seal	Repair by an authorised dealer, by personnel specially trained by LUKAS, or by LUKAS itself
		Damage to the piston	
Leak on the handhold	Increase load?	Load increase (e.g. something has fallen onto the part to be lifted, thereby suddenly increasing the load)	Secure the loads and move them by using other tools
			Move the load somewhere else, where the moving load is lighter
			Use supporting equipment to move the load.
	Does the pressure set on the pump comply with the maximum permissible pressure on the rescue equipment?	Pressure release in the Rescue tool.	Following the reduction in pressure, no further leak is present.
			Should, however, there be a further leak on the handhold, immediately deactivate the rescue equipment, and contact an authorised dealer or LUKAS itself.
Hoses in handhold loose?	Hoses in handhold not tightened	Tighten hoses.	
Check the connections of the mono-coupling (female)	Supply and return connection of the mono-coupling (female) inverted	Reconnect the hoses of the mono-coupling (female) in the right way	
<u><i>Epecially by usage of quick-disconnect-couplings:</i></u> Leak on the handhold	Is the return hose connected correctly?	Return hose is not coupled correctly or not connected.	Re-connect the return hose and secure it.

Trouble	Control	Cause	Solution
<u><i>Especially by usage of mono-couplings:</i></u> Leak on the handhold	check the connections of the hoses	hose connection to the couplings interchanged	reconnect the hoses to the coupling in the right way
		Returnline disabled	disconnect the returnline from the coupling, clean it and reconnect it.
<u><i>with mono-coupling-system:</i></u> Leak in the couplings	Is the coupling damaged?	coupling damaged	Coupling must be replaced immediately
<u><i>with quick-disconnect-coupling-system:</i></u> Leak in the couplings	Is the coupling damaged?	coupling damaged	Coupling must be replaced immediately
	Is the leak only on the coupling male?	Safety valve reacted	After pressure release there is no more leakage.

If it isn't possible to rectify the malfunctions, inform an authorised LUKAS dealer or the LUKAS customer service department immediately!
The address for the LUKAS customer service department is:

LUKAS Hydraulik GmbH
Weinstraße 39, D-91058 Erlangen
Tel.: (+49) 09131 / 698 - 348
Fax.: (+49) 09131 / 698 - 353

12. Technical data

Since all values are subject to tolerances, minor differences may occur between the data on your equipment and the data in the following schedules!



NOTE:

The following tables contain only the technical data required for standard acceptance.

Additional data concerning your unit can be obtained from LUKAS on request.

type		SP 300	
		111051000	171051000
min. spreading force (25mm / 0.98in. from the tips)	[kN] <i>[lbf.]</i>	34 <i>7,644</i>	
max. spreading force (25mm / 0.98in. from the tips)	[kN] <i>[lbf.]</i>	42 <i>9,442</i>	
spreading force HSF (according to NFPA)	[kN] <i>[lbf.]</i>	40 <i>8,993</i>	
spreading force LSF (according to NFPA)	[kN] <i>[lbf.]</i>	33 <i>7,419</i>	
max. spreading distance	[mm] <i>[in.]</i>	605 <i>23.82</i>	
min. pulling force (on mounting borehole for chain set)	[kN] <i>[lbf.]</i>	22,5 <i>5,058</i>	
max. pulling force (on mounting borehole for chain set)	[kN] <i>[lbf.]</i>	28 <i>6,294</i>	
pulling distance (on mounting borehole for chain set)	[mm] <i>[in.]</i>	495 <i>19.49</i>	
pulling force HPF (according to NFPA)	[kN] <i>[lbf.]</i>	23 <i>5,171</i>	
pulling force LPF (according to NFPA)	[kN] <i>[lbf.]</i>	19 <i>4,272</i>	
dimensions l x w x h	[mm] <i>[in.]</i>	750 x 355 x 255 <i>29.53 x 13.98 x 10.04</i>	
weight incl. hydraulic fluid	[kg] <i>[lbs.]</i>	17,1 <i>37.7</i>	
max. operating pressure	[Mpa] * <i>[psi.]</i>	70 <i>10,153</i>	
min. needed volume of hydraulic fluid	[l] ** <i>[gal.-US]</i>	0,14 <i>0.04</i>	
coupling system		quick-disconnect coupling	mono-coupling
classification acc. to DIN EN 13204		AS 34/605-17	

* 1 MPa = 10 bar

** Necessary volume of hydraulic fluid in the hydraulic unit to operate the unit (differential volume on piston / rod side)

type		SP 310	
ref. no.		111010000	171010000
min. spreading force (25mm / 0.98in. from the tips)	[kN] <i>[lbf.]</i>	46 <i>10,342</i>	
max. spreading force (25mm / 0.98in. from the tips)	[kN] <i>[lbf.]</i>	61 <i>13,714</i>	
spreading force HSF (according to NFPA)	[kN] <i>[lbf.]</i>	53 <i>11,915</i>	
spreading force LSF (according to NFPA)	[kN] <i>[lbf.]</i>	39 <i>8,768</i>	
max. spreading distance	[mm] <i>[in.]</i>	720 <i>28.35</i>	
min. pulling force (on mounting borehole for chain set)	[kN] <i>[lbf.]</i>	30 <i>6,745</i>	
max. pulling force (on mounting borehole for chain set)	[kN] <i>[lbf.]</i>	42 <i>9,442</i>	
pulling distance (on mounting borehole for chain set)	[mm] <i>[in.]</i>	575 <i>22.64</i>	
pulling force HPF (according to NFPA)	[kN] <i>[lbf.]</i>	30,5 <i>6,857</i>	
pulling force LPF (according to NFPA)	[kN] <i>[lbf.]</i>	23 <i>5,171</i>	
dimensions l x w x h	[mm] <i>[in.]</i>	790 x 350 x 190 <i>31.10 x 13.78 x 7.48</i>	
weight incl. hydraulic fluid	[kg] <i>[lbs.]</i>	20,1 <i>44.3</i>	
max. operating pressure	[Mpa] * <i>[psi.]</i>	70 <i>10,153</i>	
min. needed volume of hydraulic fluid	[l] ** <i>[gal.-US]</i>	0,24 <i>0.07</i>	
coupling system		quick-disconnect-coupling	mono-coupling
classification acc. to DIN EN 13204		AS 46/720-20	

* 1 MPa = 10 bar

** Necessary volume of hydraulic fluid in the hydraulic unit to operate the unit (differential volume on piston / rod side)

type		SP 510	
ref. no.		111030000	171030000
min. spreading force (25mm / 0.98in. from the tips)	[kN] <i>[lbf.]</i>	62 <i>13,938</i>	
max. spreading force (25mm / 0.98in. from the tips)	[kN] <i>[lbf.]</i>	92 <i>20,683</i>	
spreading force HSF (according to NFPA)	[kN] <i>[lbf.]</i>	79,9 <i>17,963</i>	
spreading force LSF (according to NFPA)	[kN] <i>[lbf.]</i>	54,6 <i>12,275</i>	
max. spreading distance	[mm] <i>[in.]</i>	800 <i>31.50</i>	
min. pulling force (on mounting borehole for chain set)	[kN] <i>[lbf.]</i>	38 <i>8,543</i>	
max. pulling force (on mounting borehole for chain set)	[kN] <i>[lbf.]</i>	55 <i>12,365</i>	
pulling distance (on mounting borehole for chain set)	[mm] <i>[in.]</i>	665 <i>26.18</i>	
pulling force HPF (according to NFPA)	[kN] <i>[lbf.]</i>	44,4 <i>9,982</i>	
pulling force LPF (according to NFPA)	[kN] <i>[lbf.]</i>	31,1 <i>6,992</i>	
dimensions l x w x h	[mm] <i>[in.]</i>	900 x 380 x 215 <i>35.43 x 14.96 x 8.46</i>	
weight incl. hydraulic fluid	[kg] <i>[lbs.]</i>	25,5 <i>56.2</i>	
max. operating pressure	[Mpa] * <i>[psi.]</i>	70 <i>10,153</i>	
min. needed volume of hydraulic fluid	[l] ** <i>[gal.-US]</i>	0,43 <i>0.12</i>	
coupling system		quick-disconnect-coupling	mono-coupling
classification acc. to DIN EN 13204		BS 62/800-25	

* 1 MPa = 10 bar

** Necessary volume of hydraulic fluid in the hydraulic unit to operate the unit (differential volume on piston / rod side)

type		SP 512	
ref. no.		111040000	171040000
min. spreading force (25mm / 0.98in. from the tips)	[kN] <i>[lbf.]</i>	84 <i>18,885</i>	
max. spreading force (25mm / 0.98in. from the tips)	[kN] <i>[lbf.]</i>	120 <i>26,978</i>	
spreading force HSF (according to NFPA)	[kN] <i>[lbf.]</i>	108 <i>24,278</i>	
spreading force LSF (according to NFPA)	[kN] <i>[lbf.]</i>	77 <i>17,311</i>	
max. spreading distance	[mm] <i>[in.]</i>	610 <i>24.02</i>	
min. pulling force (on mounting borehole for chain set)	[kN] <i>[lbf.]</i>	66 <i>14,838</i>	
max. pulling force (on mounting borehole for chain set)	[kN] <i>[lbf.]</i>	99 <i>22,257</i>	
pulling distance (on mounting borehole for chain set)	[mm] <i>[in.]</i>	437 <i>17.20</i>	
pulling force HPF (according to NFPA)	[kN] <i>[lbf.]</i>	67 <i>15,063</i>	
pulling force LPF (according to NFPA)	[kN] <i>[lbf.]</i>	49 <i>11,017</i>	
dimensions l x w x h	[mm] <i>[in.]</i>	795 x 380 x 216 <i>31.30 x 14.96 x 8.50</i>	
weight incl. hydraulic fluid	[kg] <i>[lbs.]</i>	26,4 <i>58.2</i>	
max. operating pressure	[Mpa] * <i>[psi.]</i>	70 <i>10,153</i>	
min. needed volume of hydraulic fluid	[l] ** <i>[gal.-US]</i>	0,34 <i>0.09</i>	
coupling system		quick-disconnect-coupling	mono-coupling
classification acc. to DIN EN 13204		CS 84/610-26	

* 1 MPa = 10 bar

** Necessary volume of hydraulic fluid in the hydraulic unit to operate the unit (differential volume on piston / rod side)

12.1 Peeling

Type		SP 310	SP 510	SP 512
max. sheet steel thickness "t"	[mm] [in.]	4 0.16	5 0.20	5 0.20
max. possible peeling length	[mm] [in..]	520 20.47	650 25.59	500 19.69

12.2 Recommended hydraulic fluid

Hydraulic fluid for LUKAS hydraulic equipment:

Mineral oil DIN ISO 6743-4 and others

	Oil temperature range	Oil code	Viscosity rating	Remarks
A	-20 +55°C -4.0 +131°F	HM 10	VG 10	

recommended viscosity range: 10...200 mm²/s (10...200 cSt.)

Supplied with HM 10 DIN ISO 6743-4.



CAUTION!

Before using hydraulic fluids, which do not correspond to the above-mentioned specifications and/or are not purchased from LUKAS, you have to contact LUKAS itself!

12.3 Operating and storage temperature ranges

Operating temperature	[°C] / [°F]	-20 ... +55	-4 ... +131
Ambient temperature (device in operation)	[°C] / [°F]	-25 ... +45	-13 ... +113
Storage temperature (device not in operation)	[°C] / [°F]	-30 ... +60	-22 ... +140

13. EC Declaration of conformity

LUKAS

LUKAS Hydraulik GmbH
Weinstrasse 39,
D-91058 Erlangen / Germany
www.lukas.com

IBEX RESCUE

Dingjee
Hurst
LUKAS
Vetter

- 1 / 1 -

EG-Konformitätserklärung / EC Declaration of Conformity

Im Sinne der EG-Maschinenrichtlinie 06/42/EG, Anhang II A
In accordance with the EC Machinery Directive 06/42/EG, Appendix II A

Hiermit erklären wir, dass die nachfolgend bezeichneten Spreizer
We hereby declare that the following spreaders

Artikelnr. / Item No.	Modell / Type
111051000, 171051000	SP 300
111010000, 171010000	SP 310
111030000, 171030000	SP 510
111040000, 171040000	SP 512

- in der von uns gelieferten Ausführung den Bestimmungen der Maschinenrichtlinie 06/42/EG (ersetzte Richtlinie 98/37/EG) und den sie umsetzenden nationalen Rechtsvorschriften entspricht.
Berücksichtigt wurden insbesondere die Normen:
 - DIN EN ISO 12100-1/A1, Ausgabe:2009-10 - Sicherheit von Maschinen – Grundbegriffe, allgemeine Gestaltungsleitsätze – Teil 1
 - DIN EN ISO 12100-2/A1, Ausgabe:2009-10 - Sicherheit von Maschinen – Grundbegriffe
 - allgemeine Gestaltungsleitsätze – Teil 2
 - DIN EN ISO 14121-1, Ausgabe: 2007-12 - Sicherheit von Maschinen - Leitsätze zur Risikobeurteilung
 - DIN EN 13204, Ausgabe: 2005-03 – Doppelt wirkende hydraulische Rettungsgeräte für die Feuerwehr und Rettungsdienste – Sicherheits- und Leistungsanforderungen
- in the versions supplied by us conform to the EC Machinery Directive 06/42/EG (replaced directive 98/37/EG) and the national statutory provisions that implement them.
The following standards have been taken into particular consideration:
 - DIN EN ISO 12100-1/A1, publication date: 2009-10 – Safety of machinery - Basic concepts, general principles for design - Part 1
 - DIN EN ISO 12100-2/A1, publication date: 2009-10 – Safety of machinery - Basic concepts, general principles for design - Part 2
 - DIN EN ISO 14121-1, publication date: 2007-12 – Safety of machinery – Principles for risk assessment
 - DIN EN 13204, publication date: 2005-03 – Double acting hydraulic rescue tools for fire and rescue service use – Safety and performance requirements

Bei einer nicht mit uns abgestimmten Änderung oder Verwendung der Maschine/Ausrüstung verliert diese Erklärung ihre Gültigkeit.

This declaration loses validity in the case of alterations or usage of the machinery/equipment not approved by LUKAS.

Erlangen, 25.06.2010



Carsten Sauerbier,
Leiter Entwicklung / Manager R & D
LUKAS Hydraulik GmbH



Wolfgang Bertleff,
Leiter Konstruktion / Manager Design
LUKAS Hydraulik GmbH

An IDEX Fire & Safety Business

LUKAS Hydraulik GmbH • Sitz/Domicile: Erlangen • Registergericht/Registration: Fürth HRB 6505
Geschäftsführer/Managing Directors: Sven G. Kilmner, MBA; Rainer Siegmund, Dipl.-Betriebsw. (FH)
Tel.: +49 (0)9131/698-0 • Fax: +49 (0)9131/698-394 • E-Mail: lukas.info@idexcora.com

Bank
J.P. Morgan AG Frankfurt a.M.

BLZ/Bank Code
501 108 00

Kto.-Nr./Account No.
6 161 507 041

S.W.I.F.T.-Code
CHASDEFX

IBAN
DE94 5011 0800 6161 5070 41

14. Notes



Please dispose all packaging materials and dismantled parts properly

LUKAS Hydraulik GmbH

A Unit of IDEX Corporation

Weinstraße 39, D-91058 Erlangen

Tel.: (+49) 0 91 31 / 698 - 0

Fax.: (+49) 0 91 31 / 698 - 394

e-mail: lukas.info@idexcorp.com

www.lukas.com

MADE IN GERMANY